

- Kompatybilny z modelami
 - Acer Aspire 5250
 - Acer TravelMate 5740G
 - Acer TravelMate 7740G
 - Acer TravelMate 7740Z
 - Acer TravelMate 7740ZG
 - Acer TravelMate 8572TG
 - Packard Bell EasyNote
 - Acer Aspire 5241
 - Acer Aspire 5732Z
 - Packard Bell MS2267
 - Packard Bell MS2273
 - Packard Bell EasyNote LJ61-RB
 - Packard Bell EasyNote LJ61-SB
 - Packard Bell EasyNote LJ63-RB
 - Packard Bell EasyNote LJ63-SB
 - Packard Bell EasyNote LJ65-AU
 - Packard Bell EasyNote LJ65-AV
 - Packard Bell EasyNote LJ65-CU
 - Packard Bell EasyNote LJ65-DM
 - Packard Bell EasyNote LJ65-DT
 - Packard Bell EasyNote LJ65-RB
 - Packard Bell EasyNote LJ67-CU
 - Packard Bell EasyNote LJ67-DT
 - Packard Bell EasyNote LJ71-RB
 - Packard Bell EasyNote LJ71-SB
 - Packard Bell EasyNote LJ73-RB
 - Packard Bell EasyNote LJ73-SB
 - Packard Bell EasyNote LJ75-GN
 - Packard Bell EasyNote LJ75-JN
 - Packard Bell EasyNote LJ75-JO
 - Packard Bell EasyNote LJ75-JP
 - Packard Bell EasyNote LJ77-JO
 - Acer Aspire V3-571G
 - Acer Aspire E1-771G
 - Acer Aspire E1-772G
 - Acer Aspire V3-531G
 - Acer Aspire V3-551G
 - Acer Aspire V3-771G
 - Acer Aspire V3-772G
 - Acer TravelMate 4750
 - Acer TravelMate 4750G
 - Acer TravelMate 5542
 - Acer TravelMate 5542G

- Acer TravelMate 5744Z
- Acer TravelMate 6495T
- Acer TravelMate 6495TG
- Acer TravelMate 6595
- Acer TravelMate 7750
- Acer TravelMate 7750G
- Acer TravelMate 7750Z
- Acer TravelMate 8472
- Acer TravelMate 8472G
- Acer TravelMate 8472T
- Acer TravelMate 8472TG
- Acer TravelMate 8473
- Acer TravelMate 8473T
- Acer TravelMate 8473TG
- Acer TravelMate 8572G
- Acer TravelMate 8573
- Acer TravelMate 8573T
- Acer TravelMate 8573TG
- Packard Bell EasyNote LE11-BZ
- Packard Bell EasyNote LE69-KB
- Packard Bell EasyNote LM81-RB
- Packard Bell EasyNote LM81-SB
- Packard Bell EasyNote LM82-RB
- Packard Bell EasyNote LM83-RB
- Packard Bell EasyNote LM83-SB
- Packard Bell EasyNote LM85-GU
- Packard Bell EasyNote LM85-JN
- Packard Bell EasyNote LM85-JO
- Packard Bell EasyNote LM85-JU
- Packard Bell EasyNote LM86-GN
- Packard Bell EasyNote LM86-GO
- Packard Bell EasyNote LM86-GU
- Packard Bell EasyNote LM86-JN
- Packard Bell EasyNote LM86-JO
- Packard Bell EasyNote LM87-JN
- Packard Bell EasyNote LM87-JO
- Packard Bell EasyNote LM87-JU
- Packard Bell EasyNote LM94-RB
- Packard Bell EasyNote LM94-SB
- Packard Bell EasyNote LM98-AU
- Packard Bell EasyNote LM98-CP
- Packard Bell EasyNote LM98-GO
- Packard Bell EasyNote LM98-GU
- Packard Bell EasyNote LM98-JN
- Packard Bell EasyNote LM98-JO
- Packard Bell EasyNote LM98-JU

- Packard Bell EasyNote LS11-HR
- Packard Bell EasyNote LS11-SB
- Packard Bell EasyNote LS13-HR
- Packard Bell EasyNote LS13-SB
- Packard Bell EasyNote LS44-HR
- Packard Bell EasyNote LS44-SB
- Packard Bell EasyNote LV11-HC
- Packard Bell EasyNote LV44-HC
- Packard Bell EasyNote NE11-HC
- Packard Bell EasyNote NM85-GN
- Packard Bell EasyNote NM85-GO
- Packard Bell EasyNote NM85-GU
- Packard Bell EasyNote NM85-JN
- Packard Bell EasyNote NM85-JU
- Packard Bell EasyNote NM86-GN
- Packard Bell EasyNote NM86-JN
- Packard Bell EasyNote NM87-GN
- Packard Bell EasyNote NM87-JN
- Packard Bell EasyNote NM87-JO
- Packard Bell EasyNote NM98-GU
- Packard Bell EasyNote NM98-JN
- Packard Bell EasyNote NM98-JU
- Packard Bell EasyNote NS11-HR
- Packard Bell EasyNote NS44-HR
- Packard Bell EasyNote NS45-HR
- Packard Bell EasyNote NS85-JN
- Packard Bell EasyNote TE11-BZ
- Packard Bell EasyNote TE11-HC
- Packard Bell EasyNote TE11-HR
- Packard Bell EasyNote TK11-BZ
- Packard Bell EasyNote TK13-BZ
- Packard Bell EasyNote TK36-AU
- Packard Bell EasyNote TK36-AV
- Packard Bell EasyNote TK36-CV
- Packard Bell EasyNote TK36-RV
- Packard Bell EasyNote TK37-AU
- Packard Bell EasyNote TK37-AV
- Packard Bell EasyNote TK81-RB
- Packard Bell EasyNote TK81-SB
- Packard Bell EasyNote TK83-RB
- Packard Bell EasyNote TK83-SB
- Packard Bell EasyNote TK85-CV
- Packard Bell EasyNote TK85-GN
- Packard Bell EasyNote TK85-GO
- Packard Bell EasyNote TK85-GU
- Packard Bell EasyNote TK85-JN

- Packard Bell EasyNote TK85-JO
- Packard Bell EasyNote TK85-SB
- Packard Bell EasyNote TK87-GN
- Packard Bell EasyNote TK87-GO
- Packard Bell EasyNote TK87-GU
- Packard Bell EasyNote TK87-JN
- Packard Bell EasyNote TK87-JU
- Packard Bell EasyNote TM01-RB
- Packard Bell EasyNote TM01-SB
- Packard Bell EasyNote TM05-GU
- Packard Bell EasyNote TM05-JN
- Packard Bell EasyNote TM80-RB
- Packard Bell EasyNote TM81-RB
- Packard Bell EasyNote TM81-SB
- Packard Bell EasyNote TM82-RB
- Packard Bell EasyNote TM82-SB
- Packard Bell EasyNote TM83-RB
- Packard Bell EasyNote TM83-SB
- Packard Bell EasyNote TM85-GN
- Packard Bell EasyNote TM85-GO
- Packard Bell EasyNote TM85-JN
- Packard Bell EasyNote TM85-JO
- Packard Bell EasyNote TM85-JU
- Packard Bell EasyNote TM86-GN
- Packard Bell EasyNote TM86-JO
- Packard Bell EasyNote TM86-JP
- Packard Bell EasyNote TM87-GN
- Packard Bell EasyNote TM87-GU
- Packard Bell EasyNote TM87-JN
- Packard Bell EasyNote TM87-JO
- Packard Bell EasyNote TM89-GN
- Packard Bell EasyNote TM89-GU
- Packard Bell EasyNote TM93-RB
- Packard Bell EasyNote TM94-RB
- Packard Bell EasyNote TM94-SB
- Packard Bell EasyNote TM97-GN
- Packard Bell EasyNote TM98-GN
- Packard Bell EasyNote TM98-JO
- Packard Bell EasyNote TM99-GN
- Packard Bell EasyNote TS11-HR
- Packard Bell EasyNote TS11-SB
- Packard Bell EasyNote TS13-HR
- Packard Bell EasyNote TS13-SB
- Packard Bell EasyNote TS44-HR
- Packard Bell EasyNote TS44-SB
- Packard Bell EasyNote TS45-HR

- Packard Bell EasyNote TS45-SB
- Packard Bell EasyNote TSX62-HR
- Packard Bell EasyNote TSX66-HR
- Packard Bell EasyNote TV11-CM
- Packard Bell EasyNote TV11-HC
- Packard Bell EasyNote TV43-CM
- Packard Bell EasyNote TV43-HC
- Packard Bell EasyNote TV44-CM
- Packard Bell EasyNote TV44-HC
- Packard Bell EasyNote TV44-HR
- Acer TravelMate 7720G
- Acer TravelMate 6594E
- Acer TravelMate 6594G
- Packard Bell EasyNote LK11-BZ
- Packard Bell EasyNote LK12-BZ
- Packard Bell EasyNote LK13-BZ
- Acer TravelMate 4314WXMI
- Packard Bell EasyNote TH36-AU
- Packard Bell EasyNote TJ61-RB
- Packard Bell EasyNote TJ61-SB
- Packard Bell EasyNote TJ62-RB
- Packard Bell EasyNote TJ62-SB
- Packard Bell EasyNote TJ64-RB
- Packard Bell EasyNote TJ65-AU
- Packard Bell EasyNote TJ65-CU
- Packard Bell EasyNote TJ65-DT
- Packard Bell EasyNote TJ66-AU
- Packard Bell EasyNote TJ66-CU
- Packard Bell EasyNote TJ66-DM
- Packard Bell EasyNote TJ66-DT
- Packard Bell EasyNote TJ67-AU
- Packard Bell EasyNote TJ67-CU
- Packard Bell EasyNote TJ68-AU
- Packard Bell EasyNote TJ71-RB
- Packard Bell EasyNote TJ71-SB
- Packard Bell EasyNote TJ72-RB
- Packard Bell EasyNote TJ72-SB
- Packard Bell EasyNote TJ73-RB
- Packard Bell EasyNote TJ73-SB
- Packard Bell EasyNote TJ74-RB
- Packard Bell EasyNote TJ75-GN
- Packard Bell EasyNote TJ75-JN
- Packard Bell EasyNote TJ75-JO
- Packard Bell EasyNote TJ76-GN
- Packard Bell EasyNote TJ76-JN
- Packard Bell EasyNote TJ76-JO

- Packard Bell EasyNote TJ76-JU
- Packard Bell EasyNote TJ76-NJ
- Packard Bell EasyNote TJ77-GN
- Packard Bell EasyNote TJ77-JN
- Packard Bell EasyNote TJ77-JU
- Packard Bell EasyNote TJ78-GO
- Packard Bell EasyNote TJ78-JN
- Packard Bell EasyNote TR81-SB
- Packard Bell EasyNote TR82-SB
- Packard Bell EasyNote TR83-SB
- Packard Bell EasyNote TR85-DT
- Packard Bell EasyNote TR86-BU
- Packard Bell EasyNote TR86-DM
- Packard Bell EasyNote TR86-MD
- Packard Bell EasyNote TR86-TD
- Packard Bell ZH7
- Acer Aspire 5501WXCi
- Acer Aspire 5501WXMi
- Acer Aspire 5502WXCi
- Acer Aspire 5502WXMi
- Acer Aspire 5502ZWXCi
- Acer Aspire 5502ZWXMi
- Acer Aspire 5504WXMi
- Acer Aspire 5561AWXMi
- Acer Aspire 5562WXMi
- Acer Aspire 5563WXMi
- Acer Aspire 5572AWXMi
- Acer Aspire 5573ZWXMi
- Acer Aspire 5575ZNWXMi
- Acer Aspire 5583NWXMi
- Acer Aspire 5583WXMi
- Acer Aspire 5584WXMi
- Acer Aspire 5585WXMi
- Acer Aspire 5611AWLMI
- Acer Aspire 5611ZWLMI
- Acer Aspire 5612AWLMI
- Acer Aspire 5612WLMi
- Acer Aspire 5613AWLMI
- Acer Aspire 5632WLMi
- Acer Aspire 5633WLMi
- Acer Aspire 5634WLMi
- Acer Aspire 5683WLMi
- Acer Aspire 5684WLMi
- Acer Aspire 5685WLMi
- Acer Aspire 5745
- Acer Aspire 5745DG

- Acer Aspire 5745G
- Acer Aspire 5745P
- Acer Aspire 5745PG
- Acer Aspire 5820
- Acer Aspire 5820G
- Acer Aspire 5820T
- Acer Extensa 5513WLMi
- Acer TravelMate 2428AWXMi
- Acer TravelMate 2482WXMi
- Acer TravelMate 2483WXMi
- Acer TravelMate 2484WXMi
- Acer TravelMate 2490WLMi
- Acer TravelMate 3242NWXMi
- Acer TravelMate 3260WXMi
- Acer TravelMate 3262WXMi
- Acer TravelMate 4202WLMi
- Acer TravelMate 4283WLMi
- Acer TravelMate 7520
- Acer TravelMate 7520G
- Packard Bell EasyNote F0336-V
- Packard Bell Easynote MB85-P
- Packard Bell EasyNote MX67-P
- Packard Bell EasyNote MZ35-U
- Packard Bell EasyNote MZ35-V
- Packard Bell EasyNote MZ36-R
- Packard Bell EasyNote MZ36-T
- Packard Bell EasyNote MZ36-U
- Packard Bell EasyNote MZ36-V
- Packard Bell EasyNote SB88-P
- Packard Bell EasyNote SB89-P
- LITEON PA-1900
- Acer TravelMate 6594EG
- Packard Bell EasyNote MX36-R
- Packard Bell EasyNote MX36-T
- Packard Bell EasyNote MX36-U
- Packard Bell EasyNote MX37-T
- Packard Bell EasyNote MX37-U
- Packard Bell EasyNote MX37-V
- Packard Bell EasyNote MX45-P
- Packard Bell EasyNote MX51-B
- Packard Bell EasyNote MX52-B
- Packard Bell Easynote MX52-B
- Packard Bell EasyNote MX52-F
- Packard Bell EasyNote MX67-O
- Acer Aspire V7
- Acer Aspire E1

- Acer Aspire E5
- Acer Aspire V3
- Acer Aspire V3-551
- Acer Aspire V3-571
- Acer Aspire V3-731
- Acer Aspire V3-771
- Packard Bell GM
- Packard Bell GP
- Packard Bell GP1W
- Packard Bell GP2
- Packard Bell GP2W
- Packard Bell GP3
- Packard Bell GP3W
- Packard Bell MGM00
- Packard Bell MGP00
- Packard Bell MGP20
- Packard Bell MGP30
- Packard Bell MZ35
- Packard Bell MZ36
- Packard Bell SB65
- Packard Bell SB85
- Packard Bell SB86
- Packard Bell SB88
- Packard Bell SB89
- Acer Aspire E5-572G
- Acer Aspire V3-472
- Acer Aspire V3-472G
- Acer Aspire V3-472P
- Acer Extensa EX2509
- Acer Extensa EX2510
- Acer Extensa EX2510G
- Acer TravelMate TMP246
- Acer TravelMate TMP256
- Acer Aspire E5-575
- Acer Aspire E5-575G
- Acer Aspire 5253
- Acer Aspire 5253G
- Acer Aspire 5733
- Acer Aspire 5733Z
- Acer Aspire 5749
- Acer Aspire 5749G
- Acer Aspire 5749Z
- Acer Aspire 5749ZG
- Acer Aspire 5750
- Acer Aspire 5750G
- Acer Aspire 5750TG

- Acer Aspire 5750Z
- Acer Aspire 7741
- Acer Aspire 7741G
- Acer Aspire 7741Z
- Acer Aspire 7741ZG
- Acer Aspire 7750
- Acer Aspire 7750G
- Acer TravelMate 5740ZG
- Acer TravelMate 5744
- Acer TravelMate 5744G
- Acer TravelMate 7740
- Acer TravelMate 8572
- Acer TravelMate 8572T
- Acer TravelMate 8572Z
- Acer Aspire 5350
- Acer Aspire E1-731
- Acer Aspire E1-731G
- Acer Aspire E1-771
- Acer Aspire V3-471
- Acer Aspire V3-471G
- Acer Aspire V3-531
- Acer Aspire V3-731G
- Acer TravelMate 4750GZ
- Acer TravelMate 4750Z
- Acer TravelMate 6495
- Acer TravelMate 6495G
- Acer TravelMate 6595G
- Acer TravelMate 6595T
- Acer TravelMate 6595TG
- Acer TravelMate 7340
- Acer TravelMate 7750ZG
- Acer TravelMate 8472Z
- Acer TravelMate 8473G
- Acer TravelMate 8473Z
- Acer TravelMate 8573G
- eMachines MS2305
- Delta Electronics ADP
- Acer Aspire 5236
- Acer Aspire 5242
- Acer Aspire 5335
- Acer Aspire 5535
- Acer Aspire 5535G
- Acer Aspire 5535Z
- Acer Aspire 5517
- Acer Aspire 5532
- Acer Aspire 5732ZG

- Acer Aspire 7315
- Acer TravelMate 5210
- Dell Alienware M9750
- Acer Aspire V5
- Acer Aspire 5103WLM1
- Acer Aspire 7720
- Acer Aspire 7720G
- Acer Aspire 7720Z
- Acer Aspire 7720ZG
- Acer Aspire M5
- Acer Aspire M5-583P
- Acer Aspire R7
- Acer Aspire R7-571
- Acer Aspire R7-571G
- Acer Aspire V5-552PG
- Acer Aspire V5-572G
- Acer Aspire V5-573G
- Acer TravelMate 7530
- Acer TravelMate 7530G
- Acer TravelMate 5220
- Acer TravelMate 5220G
- Acer TravelMate 5520
- Acer TravelMate 5520G
- Acer TravelMate 5530
- Acer TravelMate 5530G
- Acer TravelMate 7320
- Acer TravelMate 7720
- Acer Aspire 5320G
- Acer Aspire 5320Z
- Acer Aspire 7735
- Acer Aspire 7735G
- Acer Aspire 7735Z
- Acer Aspire 7735ZG
- Acer Aspire 7736
- Acer Aspire 7736G
- Acer Aspire 7736Z
- Acer Aspire 7736ZG
- Acer Aspire 7738
- Acer Aspire 7738G
- Acer Aspire 7740
- Acer Aspire 7740G
- Acer Aspire 5320
- Acer Aspire 5700
- Acer Aspire 5710
- Acer Aspire 5710G
- Acer Aspire 5710Z

- Acer Aspire 7230
- Acer Aspire 7235G
- Acer Aspire 7320
- Acer Aspire 7330
- Acer Aspire 7730
- Acer Aspire 7730G
- Acer Aspire 7730Z
- Acer Aspire 7730ZG
- Acer Aspire 7920
- Acer TravelMate 7230
- Acer TravelMate 7330
- Acer Travelmate 7530
- Acer TravelMate 7730
- Acer TravelMate 7730G
- Acer Extensa 5120
- Acer Extensa 5130
- Acer Extensa 5420
- Acer Extensa 5420G
- Acer TravelMate 5230
- Acer TravelMate 5630Z
- Acer TravelMate 5725
- Acer TravelMate 5725G
- Acer TravelMate 6410
- Acer TravelMate 6413
- Acer TravelMate 6413LMI
- Acer TravelMate 6413WLMi
- Acer TravelMate 6414
- Acer TravelMate 6414LMI
- Acer TravelMate 6452
- Acer TravelMate 6460
- Acer TravelMate 6463
- Acer TravelMate 6463LMI
- Acer TravelMate 6463WLMi
- Acer TravelMate 6463WLMIB
- Acer TravelMate 6464
- Acer TravelMate 6464WLMi
- Acer TravelMate 6464WLMIB
- Acer TravelMate 6465
- Acer TravelMate 6465WLMi
- Acer TravelMate 6465WLMIB
- Acer TravelMate 6552
- Acer TravelMate 6592
- Acer TravelMate 6592G
- Acer TravelMate 7220
- Acer TravelMate 7220G
- Acer Aspire V5-551

- Acer TravelMate 2423WXML
- Acer TravelMate 2424
- Acer TravelMate 2424NWXMI
- Acer TravelMate 2424WXCi
- Acer TravelMate 2424WXML
- Acer TravelMate 2428
- Acer TravelMate 2470
- Acer TravelMate 2451WLCI
- Acer TravelMate 2491
- Acer TravelMate 2491WLMi
- Acer TravelMate 4285
- Acer TravelMate 4285WLMi
- Acer TravelMate 5620
- Acer TravelMate 2301WLMi
- Acer TravelMate 4060LCii
- Acer TravelMate 4060LM
- Acer TravelMate 4100
- Acer TravelMate 4600
- Acer Aspire 5830TG
- Acer TravelMate 6594e
- Acer TravelMate 6594eG
- Acer TravelMate 4202
- Acer TravelMate 4202LMi
- Acer Aspire 5200
- Acer Aspire 5561
- Acer Aspire 5745Z
- Acer Aspire 5820TG
- Acer Aspire 7739
- Acer Aspire 7739G
- Acer Aspire 7739Z
- Acer Aspire 7739ZG
- Acer Aspire 7745
- Acer Aspire 7745G
- Acer Aspire 7745Z
- Acer TravelMate 8571
- Acer TravelMate 8571G
- Acer Aspire 9300
- Acer Aspire 9301
- Acer Aspire 9301WSMi
- Acer Aspire 9302
- Acer Aspire 9303WSMi
- Acer Aspire 9304
- Acer Aspire 9305
- Acer Aspire 9520
- Acer Aspire 5100
- Acer Aspire 5101

- Acer Aspire 5101A
- Acer Aspire 5101AWLMI
- Acer Aspire 5102
- Acer Aspire 5102AWLMI
- Acer Aspire 5102AWLMIP
- Acer Aspire 5102AWLMIP120
- Acer Aspire 5102AWLMIP80
- Acer Aspire 5102AWLMIP80F
- Acer Aspire 5102WLCI
- Acer Aspire 5102WLCIF
- Acer Aspire 5102WLMI
- Acer Aspire 5102WLMIF
- Acer Aspire 5102WLMJF
- Acer Aspire 5103
- Acer Aspire 5103WLMIP
- Acer Aspire 5110
- Acer Aspire 5611
- Acer Aspire 5611A
- Acer Aspire 5611Z
- Acer Aspire 5612
- Acer Aspire 5612A
- Acer Aspire 5613
- Acer Aspire 5613WLMI
- Acer Aspire 5652
- Acer Aspire 5652WLMI
- Acer Aspire 5683
- Acer Aspire 5683WILI
- Acer Aspire 5030
- Acer Aspire 5625G
- Acer Aspire 5820TZ
- Acer Aspire 7339
- Acer TravelMate 6594
- Acer Travelmate 6594
- Acer Aspire V5-471
- Acer Aspire V5-471P
- Acer Aspire 5562
- Acer Aspire 5562NWXML
- Acer Aspire 5563
- Acer Aspire 5596WXML
- Acer Ferrari 1100
- Acer Ferrari 1200
- Acer TravelMate 2428AWXCI
- Acer TravelMate 3242
- Acer TravelMate 3282NWXML
- Acer TravelMate 3282WXML
- Acer TravelMate 3284

- Acer TravelMate 3284WXMI
- Acer TravelMate 3302WXMI
- Acer TravelMate 3304WXMI
- Acer TravelMate 4235
- Acer TravelMate 4235WLMI
- Acer TravelMate 6492
- Acer TravelMate 6492G
- Acer TravelMate 6550
- Acer TravelMate 6553
- Acer TravelMate 6593
- Acer TravelMate 6593G
- Acer Aspire 5112
- Acer Aspire 5112NWLM
- Acer Aspire 5112WLMI
- Acer Aspire 5113
- Acer Aspire 5113NWLM
- Acer Aspire 5113WLMI
- Acer Aspire 5114
- Acer Aspire 5114WLMI
- Acer Aspire 5115WLMI
- Acer Aspire 5613ANWLMI
- Acer Aspire 5632
- Acer Aspire 5633
- Acer Aspire 5633NWLM
- Acer Aspire 5633WLM
- Acer Aspire 5633WXLMI
- Acer Aspire 5633WXMI
- Acer Aspire 5634
- Acer Aspire 5684
- Acer Aspire 5685
- Acer Aspire 5685WLHI
- Acer Extensa 5410
- Acer Extensa 5510
- Acer Extensa 5513AWLM
- Acer Extensa 5513NWML
- Acer TravelMate 2490
- Acer TravelMate 2491LCI
- Acer TravelMate 3900
- Acer TravelMate 4203
- Acer TravelMate 4230
- Acer TravelMate 4233NWLM
- Acer TravelMate 4233WLMI
- Acer TravelMate 4234
- Acer TravelMate 4234WLMI
- Acer TravelMate 4282
- Acer TravelMate 4282WLMI

- Acer TravelMate 4284
- Acer TravelMate 4284WLMi
- Acer TravelMate 4290
- Acer Aspire 5570ANWXCi
- Acer Aspire 5575ZNWXM
- Acer TravelMate 2451WLMi
- Acer TravelMate 4314
- Acer Aspire 5600AWLMi
- Acer Aspire 5601
- Acer Aspire 5601AWLMi
- Acer Aspire 5601WLMi
- Acer Aspire 5602WLMi
- Acer Aspire 5621AWLMi
- Acer Aspire 5622WLMi
- Acer Aspire 5670WLMi
- Acer Aspire 5673WLMi
- Acer Aspire 5674WLHi
- Acer Aspire 5675WLMi
- Acer Aspire 9510
- Acer Aspire 9525WSMi
- Acer TravelMate 4220AWLMi
- Acer TravelMate 4670WLMi
- Acer TravelMate 4672LMi
- Acer TravelMate 4672LMiB
- Acer TravelMate 4672WLMiB
- Acer TravelMate 4674LMi
- Acer TravelMate 4674WLMi
- Acer TravelMate 5100
- Acer TravelMate 5110
- Acer TravelMate 5610
- Acer TravelMate 5612WSMi
- Acer TravelMate 5614WSMi
- Acer TravelMate 5624WSM
- Acer TravelMate 5625WSMi
- Acer TravelMate 6500
- Acer TravelMate 7110
- Acer TravelMate 7510
- Acer TravelMate 7512AWSMi
- Acer TravelMate 7512WSMi
- Acer TravelMate 7513WSMi
- Acer TravelMate 7514
- Acer TravelMate 7514WSMi
- Acer TravelMate 4022WLMi
- Acer TravelMate 4104WLM
- Acer Aspire 5020
- Acer Aspire 5020LCi

- Acer Aspire 5020LMi
- Acer Aspire 5021
- Acer Aspire 5021LCi
- Acer Aspire 5021LMi
- Acer Aspire 5021NWLCi
- Acer Aspire 5021WLCi
- Acer Aspire 5021WLM
- Acer Aspire 5021WLMi
- Acer Aspire 5022
- Acer Aspire 5022NWLMi
- Acer Aspire 5022WLM
- Acer Aspire 5022WLMi
- Acer Aspire 5023
- Acer Aspire 5023WLMi
- Acer Aspire 5024
- Acer Aspire 5024LMi
- Acer Aspire 5024WLCi
- Acer Aspire 5024WLM
- Acer Aspire 5024WLMi
- Acer Aspire 5025WLMi
- Acer Aspire 5040
- Acer Aspire 5042WLMi
- Acer Aspire 5043
- Acer Aspire 5044
- Acer Aspire 1520
- Acer Aspire 5410
- Acer Aspire 5534
- Acer Aspire 5810TG
- Acer Aspire 9500
- Acer Aspire 9500WSMi
- Acer Aspire 9501WLMi
- Acer Aspire 9502
- Acer Aspire 9502WLMi
- Acer Aspire 9502WSMi
- Acer Aspire 9503
- Acer Aspire 9503EWSMi
- Acer Aspire 9503WLMi
- Acer Aspire 9503WSMi
- Acer Aspire 9504
- Acer Aspire 9504WLMi
- Acer Aspire 9504WSMi
- Acer Aspire 9515
- Acer Aspire MS2265
- Acer TravelMate 531
- Acer TravelMate 531LC
- Acer TravelMate 531LCi

- Acer TravelMate 531XC
- Acer TravelMate 531XCi
- Acer TravelMate 531XV
- Acer TravelMate 531XVi
- Acer TravelMate 533
- Acer TravelMate 533LC
- Acer TravelMate 533LCi
- Acer TravelMate 533XC
- Acer TravelMate 533XCi
- Acer TravelMate 533XV
- Acer TravelMate 533XVi
- Acer TravelMate 534
- Acer TravelMate 534LC
- Acer TravelMate 534LCi
- Acer TravelMate 534TL
- Acer TravelMate 534XC
- Acer TravelMate 534XCi
- Acer TravelMate 534XV
- Acer TravelMate 535
- Acer TravelMate 535LC
- Acer TravelMate 535LCi
- Acer TravelMate 536
- Acer TravelMate 536LCi
- Acer TravelMate 540
- Acer TravelMate 540LCi
- Acer TravelMate 540LMi
- Acer TravelMate 541
- Acer TravelMate 541LC
- Acer TravelMate 541LCi
- Acer TravelMate 541LCib
- Acer TravelMate 541LMi
- Acer TravelMate 541XCi
- Acer TravelMate 541XV
- Acer TravelMate 542
- Acer TravelMate 542LCi
- Acer TravelMate 542LMi
- Acer TravelMate 543
- Acer TravelMate 543LCi
- Acer TravelMate 543LMi
- Acer TravelMate 550
- Acer TravelMate 550LC
- Acer TravelMate 550LV
- Acer TravelMate 550XV
- Acer TravelMate 551
- Acer TravelMate 551XV
- Acer TravelMate 553

- Acer TravelMate 600
- Acer TravelMate 600TER
- Acer TravelMate 602
- Acer TravelMate 602TER
- Acer TravelMate 603
- Acer TravelMate 603TER
- Acer TravelMate 604
- Acer TravelMate 604TER
- Acer TravelMate 610
- Acer TravelMate 610TXC
- Acer TravelMate 610TXV
- Acer TravelMate 610TXVi
- Acer TravelMate 610TXVI
- Acer TravelMate 611
- Acer TravelMate 611TXC
- Acer TravelMate 611TXCi
- Acer TravelMate 611TXCI
- Acer TravelMate 611TXV
- Acer TravelMate 612
- Acer TravelMate 612TXC
- Acer TravelMate 612TXCi
- Acer TravelMate 612TXV
- Acer TravelMate 612TXVI
- Acer TravelMate 613
- Acer TravelMate 613TXC
- Acer TravelMate 613TXCi
- Acer TravelMate 613TXV
- Acer TravelMate 614
- Acer TravelMate 614TXC
- Acer TravelMate 614TXCi
- Acer TravelMate 614TXV
- Acer TravelMate 614TXVCI
- Acer TravelMate 8200
- Acer TravelMate 8202WLMi
- Acer TravelMate 8204WLMi
- Acer TravelMate 8431
- Acer TravelMate 8471
- Acer TravelMate 8471G
- Acer TravelMate 8531
- eMachines M6809
- eMachines M6810
- eMachines M6811
- eMachines W4605
- eMachines W4620
- eMachines W4630
- Gateway 8000

- Gateway 8500
- Gateway 8510
- Gateway 8510GH
- Gateway 8510GZ
- Gateway 8515
- Gateway 8515GZ
- Gateway 8550
- Gateway 8550GB
- Gateway M680
- Gateway M685
- Gateway ML3000
- Gateway ML3108
- Gateway ML3108B
- Gateway ML3108Q
- Gateway ML3108V
- Gateway ML3108Z
- Gateway ML3109
- Gateway ML3706
- Gateway ML6000
- Gateway ML6018
- Gateway ML6020
- Gateway ML6226
- Gateway ML6226B
- Gateway ML6227
- Gateway ML6227B
- Gateway ML6227Q
- Gateway ML6227v
- Gateway ML6227Z
- Gateway ML6228
- Gateway MP8708
- Gateway MP8709
- Gateway MT3000
- Gateway MT3100
- Gateway MT3110C
- Gateway MT3300
- Gateway MT3303J
- Gateway MT3410
- Gateway MT3419
- Gateway MT3420
- Gateway MT3423
- Gateway MT3700
- Gateway MT3705
- Gateway MT3707
- Gateway MT3708
- Gateway MT3710
- Gateway MT3710C

- Gateway MT3711C
- Gateway MT6000
- Gateway MT6010
- Gateway MT6020
- Gateway MT62
- Gateway MT6220
- Gateway MT6450
- Gateway MT6451
- Gateway MT6452
- Gateway MT6723
- Gateway MT6728
- Gateway MT6729
- Gateway MT6730
- Gateway MT6820
- Gateway MT6830
- Gateway MT6840
- Gateway MT6841
- Gateway MT6910
- Gateway MT6916
- Gateway MT6920
- Gateway MX3100
- Gateway MX3103b
- Gateway MX3130
- Gateway MX3140
- Gateway MX3142M
- Gateway MX3143M
- Gateway MX3300
- Gateway MX3310
- Gateway MX3311
- Gateway MX3311b
- Gateway MX3400
- Gateway MX3410
- Gateway MX3410h
- Gateway MX3412
- Gateway MX3412h
- Gateway MX3414
- Gateway MX3416
- Gateway MX3417
- Gateway MX3420
- Gateway MX3422
- Gateway MX3700
- Gateway MX3701
- Gateway MX3702
- Gateway MX6000
- Gateway MX6002M
- Gateway MX6003M

- Gateway MX6004M
- Gateway MX6005M
- Gateway MX6020
- Gateway MX6030
- Gateway MX6035
- Gateway MX6100
- Gateway MX6110
- Gateway MX6120
- Gateway MX6121
- Gateway MX6123
- Gateway MX6124
- Gateway MX6124h
- Gateway MX6128
- Gateway MX6130
- Gateway MX6135
- Gateway MX6137
- Gateway MX6200
- Gateway MX6210
- Gateway MX6214
- Gateway MX6216
- Gateway MX6240
- Gateway MX6400
- Gateway MX6410
- Gateway MX6441
- Gateway MX6442
- Gateway MX6444h
- Gateway MX6445
- Gateway MX6625
- Gateway MX6625h
- Gateway MX6627
- Gateway MX6627h
- Gateway MX6629
- Gateway MX6629h
- Gateway MX6630
- Gateway MX6631
- Gateway MX6633
- Gateway MX6633h
- Gateway MX6640
- Gateway MX6640b
- Gateway MX6641
- Gateway MX6641h
- Gateway MX6650
- Gateway MX6650h
- Gateway MX6708
- Gateway MX6708h
- Gateway MX6710

- Gateway MX6750
- Gateway MX6830
- Gateway MX6900
- Gateway MX6901
- Gateway MX6910
- Gateway MX6912
- Gateway MX6916
- Gateway MX6919
- Gateway MX6920
- Gateway MX6927
- Gateway MX6928
- Gateway MX6930
- Gateway MX6931
- Gateway MX6940
- Gateway MX6950
- Gateway MX6951
- Gateway MX6951h
- Gateway MX6955
- Gateway MX6961
- Gateway MX8000
- Gateway MX8500
- Gateway MX8520
- Gateway MX8523
- Gateway MX8525
- Gateway MX8528
- Gateway MX8530
- Gateway MX8550
- Gateway MX8700
- Gateway MX8710
- Gateway MX8711
- Gateway MX8716b
- Gateway MX8720
- Gateway MX8730
- Gateway MX8738
- Gateway MX8740
- Gateway NX260
- Gateway NX260X
- Gateway NX270
- Gateway NX270S
- Gateway NX500
- Gateway NX500S
- Gateway NX500X
- Gateway NX510
- Gateway NX510S
- Gateway NX510X
- Gateway NX550

- Gateway NX550X
- Gateway NX550XL
- Gateway NX560
- Gateway NX560X
- Gateway NX560XL
- Gateway NX570
- Gateway NX570S
- Packard Bell Easy
- Packard Bell Etna
- Acer ADP
- Acer PA-1900
- Chicony A090A029L
- Acer Aspire 5684WLMi
- Acer TravelMate 4283WLMi
- Acer Aspire 7745G-434G1TMN